


SHEER WINDOW SHADINGS INSTALLATION INSTRUCTIONS



3DAYBLINDS™
YOU'LL LOVE THE TREATMENT

GETTING STARTED


A few simple tools are required:



Steel Tape Measure



Pencil



Level



Flat Head And Phillips
Head Screwdriver



Hex Head Screwdriver
(Screwdriver)




Awl (Or Tool For
Starting A Screw Hole)


Included in your order is all hardware necessary for a normal installation. Additional fasteners other than those sent with your shading may be required depending on the mounting surface. Wallboard and plaster require the use of anchors such as expansion or toggle bolts. Brick, tile or stone need special plugs and drill bits. Remember to always pre-drill holes in wood to avoid splitting.

Professional installation is also available in most areas, call 800-800-3329.


STANDARD HARDWARE



Mounting Bracket
(Premium Headrail
Bracket Shown)




Wedge
(Standard With
Inside Mount)



"U" Shim




Hex Head Screw
(2 Per Mounting
Bracket)



Tension Pulley
(2 Screws And 1
Peg Included)


OPTIONAL HARDWARE



Extension Bracket



Bolt And Nut




Hold Down Brackets

BRACKET INFORMATION

Depending upon the width of the shading, additional brackets may be required and will need to be evenly spaced between the two end brackets.

FOR SHADE WIDTH OF:	CENTER SUPPORT BRACKETS
Up to 40"	2
> 40" - 72"	3
> 72" - 84"	4
> 84" - 112"	5


MAKE SURE THE MOUNTING SURFACE IS LEVEL



WARNING: If the headrail does not sit level, the Window Shading will not roll up evenly. This could damage the edges of your shading! Your Window Shading has been leveled and weighted in our factory. Shims have been provided to allow you to compensate for uneven mounting surfaces and ensure balanced operation.


NOTE: Premium headrail bracket is used in illustrations, if you have the standard bracket, follow same instructions.

INSIDE MOUNT




- The Brackets should be installed at each end, with the centerline of the brackets positioned 2" from the ends.
- 3 1/4" minimum of flat mounting surface is required to fully recess your shading.
- 3/4" minimum of flat mounting surface is required for a shallow mount.
- Use shims if necessary to ensure the headrail is mounted level.

FULLY RECESSED INSIDE MOUNT




- Low light gap wedges can be used to reduce the top light gap when the shading is mounted fully recessed. The wedge is placed between the mounting surface and the bracket with the tabs on the wedge facing down and the thick end of the wedge toward the back of the bracket.

OUTSIDE MOUNT



- The Brackets should be installed at each end, with the centerline of the brackets positioned 2" from the ends.
- 3/4" minimum of flat mounting surface required.


OUTSIDE MOUNT WITH EXTENSION BRACKETS




- Optional Extension Brackets are used to project the back of the shading up to 2 1/2" from the mounting surface.
- 2" minimum of flat mounting surface is required.
- Attach the Standard Mounting Bracket to the Extension Bracket with the nut and bolt provided.

BOTTOM RAIL STOP

Your Shading is equipped with a bottom rail stop to prevent the bottom rail from rolling up onto the headrail.





- Position the bottom rail stop so it does not interfere with the mounting brackets. The stop(s) can simply be pushed out of the way by sliding them to the left or right until they clear the brackets.
- Shadings 40" wide or less have 1 bottom rail stop. Slide the stops to the center of the shading.




- Shadings over 40" wide have 2 bottom rail stops. Slide the stops to the right and left of the center of the shading so it does not interfere with the mounting brackets.

HANGING THE SHADING

Push the rail back until it is fully engaged.



REMOVING THE SHADING



- To remove the shading, partially lower the shading and insert a flat head screwdriver as shown.
- Twist the screwdriver until the headrail disengages from the bracket.


NOTE: Tip of screwdriver must be wider than the space between headrail and bracket to force the headrail out of the bracket.

OPERATING THE SHADING

Pulling down on the back cord will lower the shading. When the window shading is completely lowered, pulling down on the back cord will open the vanes. Continued pulling in this direction will raise the fabric with the vanes in the open position. **The window shading must only be raised a maximum of 24" in this manner to avoid damaging the fabric. DO NOT reverse roll more than 24" .**

Pulling down on the front cord will close the vanes and then raise the shading.

TENSION PULLEY INSTALLATION




The beauty of your new shading has been enhanced to include an attractive color coordinated tension pulley. The tension pulley has already been attached to the cord loop of your Shading. Tension pulleys and cord tensioners reduce the risk of strangulation or entanglement when anchored properly to a wall or window casing.


NOTE: The tension pulley bracket must be mounted to wall before you attach it to the tension pulley with peg.

For option 1 or 2:


- Mount the tension pulley bracket to the wall or window frame in a position that will keep the cord loop taut and parallel with the shade.
- Use 2 screws through the holes in the Tension Pulley bracket to mount it.
- Insert the Tension Pulley into the bracket and push the pin and Tension Pulley to secure it into place.



For Option 1 or Option 2




Option 1



Option 2

For option 3:

- Position the Tension Pulley against the wall or window frame.
- Use 1 screw through the Tension Pulley to secure it into place.




Option 3


OPTIONAL INSTALLATION

HOLD DOWN BRACKETS

Hold down brackets are optional. Hold down brackets are used primarily on shadings mounted to doors or in motor homes.



- With the shading lowered to its full length, place the pin of each hold down bracket into either the front or back hole of the bottom rail end cap located at each end of the bottom rail, use a bit of pressure to break through the plastic film and push the pin into the end cap.
- Mark the mounting surface, either to the side or back of the window frame, through the holes in the hold down bracket. Make sure the hold down brackets are level and aligned with each other.
- Raise the shading and screw the hold down brackets into the mounting surface using the screws provided.
- Lower the shading and flex the hold down bracket outward so that the pin can be inserted into the hole at each end of the bottom rail. Use the same holes used when marking the mounting position of the hold down brackets.



CARE & CLEANING

The soft and delicate feel of Window Shadings belies the durability of the material. Sheer Window Shadings are created from sturdy knitted polyester fabric and may be feather dusted or vacuumed at a low suction setting. Spots or stains can be rubbed clean with a damp sponge and mild soap. To avoid discoloration of material, we recommend against the use of chemical cleaners. If necessary the shades may be professionally ultrasonically cleaned.

All knitted fabrics experience weave variations due to heat, humidity and other room conditions. These variations can result in slight bowing and dimpling of the Sheer Window Shadings material. The possible variations are minor and have been shown through case study not to detract from the beauty of this product.

CHILD SAFETY

The Consumer Product Safety Commission (CPSC) requires the use of a Tension Pulley on all loop cord systems. The use of such a device is intended to significantly reduce the occurrence of infant or small child strangulation injuries or death resulting from the looped pull cords on various window treatment products.


The Tension Pulley is installed on the draw cord at the factory.

The Tension Pulley should be mounted in the proper position to pull the cord taut in order to reduce the possibility of injury, but do not apply too much tension to the cord or your shading will not operate properly.



WARNING

Young children can strangle in cord and bead chain loops. They can also wrap cords around their necks and STRANGLE.



- Always keep cords and bead chains out of children's reach.
- Move cribs, playpens, and other furniture away from cords and bead chains. Children can climb furniture to get the cords.
- Attach tension device to wall or floor. This can prevent children from pulling cords and bead chains around their necks.



3DAYBLINDS™

YOU'LL LOVE THE TREATMENT

800-800-3329 | 3dayblinds.com